Connecting Laptop or other device w/ HDMI to Smart Classroom Projector

- 1. Press the display "ON" button on the control panel
- 1a. the "ON" button Flashes for approximately 15-60 secs while warming up the projector. While button is flashing no other buttons can be activated, When warm up is complete, Volume is preset to 50%
- 2. Connect HDMI to Wall plate or Podium Plate NOTE: HDMI cables provide video and audio
- 3. Connect HDMI cable to Laptop or other device
- 4. Press "HDMI" button on control panel
- 5. Pull down projector screen until image is in white area, showing approximately 2" of black at top of screen.
- 6. Press Volume "Up" or "Down" to adjust volume level. Indicator lights above the controls reflect changes in volume.
- 7. When done, press display "OFF" button, disconnect cables and raise projector screen
- 8. NOTE: The A/V mute button on control panel will mute audio only

If you have trouble seeing your main laptop screen on the projector after connecting,

On a Windows 7 PC, *Press the "Windows" key and "P" key then choose "Duplicate"* or go to the *START Menu >Control Panel > Displays > Connect to Projector* and select "*Duplicate*"

On a Windows 10 PC, *Press the "Windows" key and "P" key then choose "Duplicate"* or go to the *START Menu >Settings (gear icon) > Displays > Connect to Projector* and select "*Duplicate*"

On Mac go Press the "Command" and "F1" to toggle from mirror and extended screens or go to the Apple Menu >System Preferences > Displays > Arrangement and select "Mirror"

If you are having trouble with audio, try restarting your computer

Questions?

Please email laneyhelpdesk@peralta.edu